

QUICK START GUIDE


BC

TUNE760NC




HARMAN

WHAT'S IN THE BOX




POWER ON & CONNECT



POWER ON AND
AUTOMATICALLY ENTER PAIRING MODE

CHOOSE "JBL TUNE760NC" TO CONNECT

MANUAL PAIRING





POWER OFF

MANUAL PAIRING MODE

CHOOSE "JBL TUNE760NC" TO CONNECT

BUTTON COMMAND



POWER ON/OFF

ANC

WIRED LISTENING



MULTI-POINT CONNECTION



* (MAXIMUM 2 DEVICES)

ENTER PAIRING MODE WITH THE 2ND DEVICE

- 1 TO SWITCH MUSIC SOURCE, PAUSE THE MUSIC ON THE CURRENT DEVICE AND SELECT PLAY ON THE 2ND DEVICE.
- 2 PHONE CALL WILL ALWAYS TAKE PRIORITY.
- 3 IF ONE DEVICE GOES OUT OF BLUETOOTH RANGE OR POWERS OFF, YOU MAY NEED TO MANUALLY RECONNECT THE REMAINING DEVICE.
- 4 SELECT "FORGET THIS DEVICE" ON YOUR BLUETOOTH DEVICES TO DISCONNECT MULTI-POINT.




1ST
BLUETOOTH DEVICE

CHOOSE "JBL TUNE760NC" TO CONNECT



2ND
BLUETOOTH DEVICE

CHARGING





CHARGE



2 HR

LED BEHAVIORS



TECH SPEC

Model:
Driver size:
Power supply:
Weight:
Headset battery type:
Charging time:
Music play time with BT on and ANC on:
Music play time with BT on and ANC off:
Frequency response:
Impedance:
Sensitivity passive mode:
Sensitivity active mode:
Maximum SPL:
Microphone sensitivity:
Bluetooth version:
Bluetooth profile version:
Bluetooth transmitter frequency range:
Bluetooth transmitted power:
Bluetooth transmitted modulation:
Maximum operation temperature:

TUNE760NC
40 mm Dynamic Driver
5 V --- 1 A
220 g / 0.485 lbs
Polymer Li-ion battery (610 mAh / 3.7 V)
< 2 hrs from empty
35 hrs
50 hrs
20 Hz - 20 kHz
32 ohm
103 dB SPL/1 mW
95 dB SPL/1 mW
95 dB
-30 dBV/Pa
5.0
A2DP 1.3, AVRCP 1.5, HFP 1.6
2.4 GHz - 2.4835 GHz
< 10 dBm
GFSK, π/4 DQPSK, 8DPSK
45 °C



